

YASKAWA AC Drive L1000A

for Elevator Applications


200 V Class 1.5 to 110 kW 400 V Class 1.5 to 110 kW



1. Matching Every Need

Runs Induction and Synchronous Motors

■ Cutting-edge drive technology allows L1000 to run a newly installed gearless synchronous motor, or a refurbished geared induction motor. This minimizes equipment required for your application.



٠			
	Capacity Range	200 V Class 1.5 to 400 V Class 1.5 to	
ı			0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
		PM motors	 Closed Loop Vector Control for PM motors
ı			(SPM/IPM drive)
ı	Control		,
		Induction motors	 V/f Control
ı	Mode		 Open Loop Vector Control
ı			- Open Loop vector Control
			 Closed Loop Vector Control
ı			Closed Loop Vector Control

Compatible with a Wide Range of Encoders


- High-performance current vector control generates powerful starting torque and allows precision control at low speeds.
- ■Interfaces to match gearless, SPM synchronous motors and every type of absolute encoder. High resolution and pole position detection for a smooth and safe ride.

Control Mode	Starting Torque	Speed Range	Motor Encoders and Option Cards
V/f Control	150% at 3 Hz*	1:40	N/A
Open Loop Vector Control	200% at 0.3 Hz*	1:200	N/A
Closed Loop Vector Control	200% at 0 r/min*1	1:1500	Incremental Encoders: - PG-X3 (Line Driver) - PG-B3 (Complementary)
Closed Loop Vector Control for PM	200% at 0 r/min*	1:1500	Incremental Encoders: - PG-X3 (Line Driver) Absolute Encoders: - PG-F3 (EnDat,HIPERFACE) - PG-E3 (HEIDENHAIN ERN1387)

^{*} Drive and motor must be matched appropriately.

Designed Compact for Tight Machine Rooms

- Easily fit into compact machine rooms by combining the world's smallest drive in its class with the light, efficient design of a PM motor.
- ■L1000's slender design can be installed into a slender control panel. Depth of 200 mm for models up to 18.5 kW, 300 mm for 22 kW to 75kW
- Take advantage of Side-by-Side installation* when storage space is limited. *For models up to 18.5 kW.



Drive Dimension Comparison
 Example shows a 400 V Class, 15 kW drive

Reduced Operation Time and More Powerful Braking


Improved operation efficiency

■L1000 calculates the stopping distance to minimize operation time.

"Direct Landing" function is also available.

These features improve operation efficiency as well as greater stopping precision.

■ Short Floor minimizes the "creep speed" time for faster, more efficient operation.



Loaded with Auto-Tuning Features

- ■L1000 is loaded with a variety of Auto-Tuning methods to ensure top performance.
- Rotational Auto-Tuning and Stationary Auto-Tuning are available for induction motors as well as synchronous motors.

 Motor tuning features optimize drive settings without needing to disconnect the rope or car.
- ■Tuning features for connected machinery.
 - Types of Auto-Tuning

• • • • • • • • • • • • • • • • • • • •	
Motor Tuning	
Rotational Auto-Tuning	Applications requiring high starting torque, high speed, and high accuracy. Tuning is performed on the motor alone, uncoupled from the load.
Stationary Auto-Tuning	Applications where the motor must remain connected to the load during the auto-tuning process.
Motor Resistance Auto-Tuning	For re-tuning when the cable length between the motor/drive has changed or when motor/drive capacities are different.
Encoder Offset Auto-Tuning	Fine tunes the home pulse position when using an encoder with a synchronous motor. Possible with both Rotational and Stationary Auto-Tuning

Load Tuning


Optimizes deceleration time, Feed Forward, and functions (available soon)

■Brand new Auto-Tuning methods allow L1000 to continuously analyze changes in motor characteristics during run for highly precise speed control (when using Open Loop Vector Control)

2. Smooth, Comfortable Ride

Smooth Operation


- ■L1000 has ½ the torque ripple compared to our earlier models, for an even smoother ride.
- Designed specifically for elevator applications, L1000 provides precise motor torque performance capability for smoother acceleration and deceleration.



●Torque Ripple Comparison (Closed Loop Vector at zero speed)


Overshoot and Anti-Vibration Control

- Feed Forward achieves ideal speed response, eliminating vibration and overshoot, and makes it easy to tweak the speed control loop (ASR). (Available soon)
- Adjust jerk settings at the start and end of acceleration and deceleration to create a perfectly smooth ride.




High Performance Starting Torque without Sensors

■ Even without a load sensor, high-performance torque compensation (Advanced Anti-Rollback*) and high-resolution absolute encoder eliminate shock when the brake is released. Simplifying load sensor control signals makes cumbersome adjustments unnecessary.




- * Advanced Anti-Rollback: Torque compensation function that eliminates shock at start up by preventing the car from moving when the brake is released.
- Anti-Rollback with sensors is easy to adjust, preventing shock start and stop.




(After adjustment)

Variety of Braking Functions

All models up to 30 kW are equipped with a braking transistor for even more powerful braking options by just adding a braking resistor.







3. Safety

Rescue Operation

Rescue Operation switches to backup battery or UPS in case of a power outage

- ■Both single-phase and 3-phase 220 V UPS and 48-96 Vdc battery (24 V control power supply) can keep the elevator running in case of an emergency. Possible with all 200 V and 40 V class models (400 V class requires a 400 V class UPS)
- ■L1000 automatically adjusts speed if a voltage drop occurs to prevent loss in motor speed.
- ■Light Load Direction Search function triggered by UPS and battery voltage is provided.





●UPS Wiring and Operation

Safe Disable Function

- Backup Battery Wiring and Operation
- * The illustrations above have been simplified, omitting switches and control signals that are otherwise required. Refer to the wiring diagrams included with the components in question.


Safe Disable Function

Protect the elevator application with immediate fault detection.

■L1000 protects the entire elevator application by detecting overacceleration, speed reversal, wiring errors, and improper parameter settings.

Hardware sensors respond immediately if the motor encoder signal is lost, ensuring an even higher level of safety.

Overacceleration Fault Detection



Preventative Warnings

Performance Life Monitors


- ■L1000 is equipped with performance life monitors that notify the user of part wear and maintenance periods to prevent problems before they occur.
 - ●Alarm Signals Output PLC or Control Device



	Operator Display	Corresponding Component
	LT-1	Cooling fan
	LT-2	Capacitors
4	LT-3	Inrush prevention relay
	LT-4	IGBTs

Safety regulations

■ Fully compliant with EN954-1 Cat. 3, ISO13849-1 (Cat. 3, PLd), and IEC/EN61058 SIL2, while eliminating the need for extra peripherals. Helps to easily satisfy EU standard for elevators EN81-1.



Monitor status of input power supply

Customized hardware immediately detects phase loss from the input power supply.

Detection remains active regardless of whether the drive is running or stopped.

An output signal can also be setup if a phase loss occurs.

Long-Life Performance

Ten Years of Durable Performance


- Cooling fan, capacitors, relays, and IGBTs have been carefully selected and designed for a life expectancy up to ten years*.
 - *Assumes the drive is running continuously for 24 hours a day, 60 s/cycle, at 80% load, and an ambient temperature of 40°C.




4. Environmental

High Efficiency: Energy Saving

- Superior efficiency and control with an IPM motor and Yaskawa's Energy Saving function Achieve even greater efficiency with a IPM motor and L1000's optimized control functions.
- Re-use regenerative power by adding a regenerative unit (R1000) Combining L1000 with R1000 to send regenerative power back to the power supply.
- ■L1000 is incredibly efficient—approximately 97%. Save even more energy by using the cooling fan ON/OFF control function when the cooling fan is not needed.
- Maximizing Control Efficiency with an IPM Motor (minimizing output current (I) during operation)



■Regenerative Power Supply with R1000 (re-using regenerative energy)




High Performance: Low Harmonic Distortion

- ■Built-in DC reactor suppresses harmonic distortion to keep the input power factor above 90%.
 - * Models 18.5 kW and below offer a built-in DC reactor as an option.



●Input Current Waveform No reactor



RoHS

■ All standard products are fully compliant with the EU's RoHS directive.



■Yaskawa also offers 12-pulse and 18-pulse rectifier options*, as well as filters to minimize harmonic distortion.

* Available soon. Requires a separate 3-winding or 4-winding transformer.

5. Easy Setup and Maintenance

Terminal Block with Parameter Backup

The Drive Industry's First Terminal Board with a Parameter **Backup Function**

- ■The terminal block's ability to save parameter setting data makes it a breeze to get the application back online in the event of a failure requiring drive replacement.
 - ●L1000A Terminal Block



Parameter		
Name	Number	Setting
Control Mode Selection	A1-02	0
Frequency Reference Selection 1	b1-01	1
Run Command Selection 1	b1-02	1

Easy Setup

Quick setup and easy maintenance

40%

- Set speed, acceleration, and jerk parameters in elevator units.
- All models come standard with an LED unit equipped with a Copy function that lets the user quickly upload and download parameter settings.
- LCD operator keypad option available
- USB Copy Unit is available to copy parameter settings and program multiple drives instantly.
- The Setup Mode gives the user access to just those parameters needed to get the drive up and running right away.
- The Verify Function lets the user check parameters that may have been changed from their default values.









- **LED Operator** (standard)
- LCD Operator (optional)
- ●USB Copy Unit (optional)

Verify Function

List of parameters that have been changed from their default settings.

Parameter Name	No.	Default	Set value
Speed reference selection	b1-01	1	0
Acceleration time	C1-01	3.00s	3.50s
Deceleration time	C1-02	3.00s	3.50s
:	:	:	
	'		

DriveWizard Plus

Engineering Tool DriveWizard Plus

- Manage the unique settings for all your drives with a personal computer (PC).
- ■An indispensable tool for drive setup and maintenance. Edit parameters, access all monitors, create customized operation sequences, and observe drive performance with the oscilloscope function.
- The Drive Replacement feature in DriveWizard Plus saves valuable time during equipment replacement and application upgrades by automatically programming parameters for full compatibility.
- ■Equipped with a USB port for easy connection to a personal computer.
 - ●Connecting L1000 and a PC with USB



Note: Users can also use the WV103 cable included with earlier Yaskawa models. Simply remove the operator keypad to access the comm. port.

Standard Specifications

■ 200 V Class

		ltem									Specifi	cations							
Model	Model CIMR-LT2A:			8000	0011	0018	0025	0033	0047	0060	0075	0085	0115	0145	0180	0215	0283	0346	0415
Мах. Ар	Max. Applicable Motor Capacity*1 kW		kW	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110
Input			Α	7.5	11	18.9	28	37	52	68	80	82	111	136	164	200	271	324	394
	Rated Ou	tput Capacity*3	kVA	3*4	4.2^{*4}	6.7*4	9.5*4	12.6*4	17.9*4	23*4	29* ⁴	32*4	44*4	55* ⁵	69*5	82*5	108*5	132*5	158 ^{*5}
	Rated Ou	tput Current	Α	8*4	11*4	17.5* ⁴	25*4	33* ⁴	47*4	60*4	75* ⁴	85*4	115*4	145*5	180* ⁵	215*5	283*5	346*5	415*5
	Overload Tolerance								150	% of rat	ed outp	ut curre	nt for 60	0 s*6					
Output	Carrier Fr	equency				U	ser adji	ustable	from 2 t	o 15 kH	z				Us	•	stable fr 10 kHz	om	
	Max. Out	out Voltage						Three	e-phase	200 to	240 V (p	oroportio	onal to i	nput vo	ltage)				
	Max. Out	out Frequency								200 l	Hz (use	r adjust	able)						
	Rated Vo	tage/Rated Freq	uency	Three-phase 200 to 240 Vac 50/60 Hz 270 to 340 Vdc															
Power	Allowable	Voltage Fluctuat	tion								-15 to	10%							
rowei	Allowable	Frequency Fluct	uation								±	5%							
	Power Su	pply	kVA	4.1	5.8	9.5	14	18	27	36	44	37	51	62	75	91	124	148	180
Harmon Suppres		DC Reactor					Op	tion							Bui	lt-in			
Braking	Function	Braking Resistor	r					Bui	lt-in							Ор	tion		

- * 1: The motor capacity (kW) refers to a Yaskawa 4-pole induction motor (200 V, 60 Hz). The rated output current of the drive output amps should be equal to or greater than the motor rated current.
- * 2: Value displayed is for when operating at the rated output current. This value may fluctuate based on the power supply side impedance, as well as the input current, power supply transformer, input side reactor, and wiring conditions.
- * 3: Rated output capacity is calculated with a rated output voltage of 220 V.
- * 4: Carrier frequency is set to 8 kHz. Current derating is required in order to raise the carrier frequency.
- * 5: Carrier frequency is set to 5 kHz. Current derating is required in order to raise the carrier frequency.
- * 6: Peak current should be kept under 150%. Be sure to check current levels during a test run, and make adjustments accordingly. Repeatedly exceeding 150% of the rated current causes thermal wear on the drive's IGBTs, and will shorten their expected performance life. The drive is rated to start and stop three million times, assuming the carrier frequency is left at its default setting with a peak current of 150%.

400 V Class

	Item										Specifi	cations							
Model	Model CIMR-LT4A			0005	0006	0009	0015	0018	0024	0031	0039	0045	0060	0075	0091	0112	0150	0180	0216
Мах. Ар	1		kW	1.5	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	90	110
Input	1111 1111 1111		Α	4.4	6	10.4	15	20	29	39	44	43	58	71	86	105	142	170	207
	Rated Ou	tput Capacity*3	kVA	3.7 ^{*4}	4.2 ^{*4}	7*4	11.3 ^{*4}	13.7 ^{*4}	18.3 ^{*4}	24*4	30 ^{*4}	34 ^{*4}	48 ^{*4}	57 ^{*4}	69 ^{*4}	85 ^{*5}	114 ^{*5}	137 ^{*5}	165 ^{*5}
	Rated Ou	tput Current	Α	4.8 ^{*4}	5.5 ^{*4}	9.2 ^{*4}	14.8*4	18 ^{*4}	24 ^{*4}	31 ^{*4}	39 ^{*4}	45 ^{*4}	60 ^{*4}	75 ^{*4}	91 ^{*4}	112 ^{*5}	150 ^{*5}	180 ^{*5}	216 ^{*5}
	Overload Tolerance								150	% of rat	ed outp	ut curre	nt for 6	0 s*6				-	
Output					User adjustable from 2 to 15 kHz User adjustable from 2 to 10 kHz												n 2 to		
	Max. Out	put Voltage						Three	e-phase	380 to	480 V (proporti	onal to i	nput vo	ltage)				
	Max. Out	put Frequency								200 I	Hz (use	r adjust	able)						
	Rated Vo	Itage/Rated Freque	ency	Three-phase 380 to 480 Vac 50/60 Hz 510 to 680 Vdc															
Power	Allowable	Voltage Fluctuation	n								-15 to	10%							
Power	Allowable	Frequency Fluctu	ation								±	5%							
	Power Su	ipply	kVA	4.3	6.1	10.0	14.6	19.2	28.4	37.5	46.6	39.3	53.0	64.9	78.6	96.0	129.9	155	189
Harmon Suppres		DC Reactor					Op	tion							Bui	lt-in			
Braking	Function	Braking Resistor						Bui	lt-in							Ор	tion		

- * 1: The motor capacity (kW) refers to a Yaskawa 4-pole induction motor (400 V, 60 Hz). The rated output current of the drive output amps should be equal to or greater than the motor rated current.
- * 2: Value displayed is for when operating at the rated output current. This value may fluctuate based on the power supply side impedance, as well as the input current, power supply transformer, input side reactor, and wiring conditions.
- * 3: Rated output capacity is calculated with a rated output voltage of 440 V.
- * 4: Carrier frequency is set to 8 kHz. Current derating is required in order to raise the carrier frequency.
- * 5: Carrier frequency is set to 5 kHz. Current derating is required in order to raise the carrier frequency.
- * 6: Peak current should be kept under 150%. Be sure to check current levels during a test run, and make adjustments accordingly. Repeatedly exceeding 150% of the rated current causes thermal wear on the drive's IGBTs, and will shorten their expected performance life. The drive is rated to start and stop three million times, assuming the carrier frequency is left at its default setting with a peak current of 150%.

■ Common Specifications

Note: Specifications regarding Open Loop Vector Control capabilities require Rotational Auto-Tuning.

L1000 must be used in acceptable environmental conditions to ensure the expected performance life of all drive components.

	ltem	Specification
	Control Method	Use drive parameters to select from the following control modes: V/f Control, Open Loop Vector Control, Closed Loop Vector Control, Closed Loop Vector Control for PM
	Frequency Control Range	0.01 to 200 Hz
	Frequency Accuracy (Temperature Fluctuation)	Digital reference: within $\pm 0.01\%$ of the max. output frequency (-10 to +40°C) Analog reference: within $\pm 0.1\%$ of the max. output frequency (25°C ± 10 °C)
	Frequency Setting Resolution	Digital reference: 0.01 Hz Analog reference: 0.03 Hz / 60 Hz (11 bit)
	Output Frequency Resolution	0.001 Hz
	Frequency Setting Resolution	-10 to 10 V, 0 to 10 V
eristics	Starting Torque	150% / 3 Hz (V/f Control) 200% / 0 r/min (Closed Loop Vector Control) 200% / 0.3 Hz (Open Loop Vector Control) 200% / 0 r/min (Closed Loop Vector Control for PM)
Characteristics	Speed Control Range	1:40 (V/f Control) 1:1500 (Closed Loop Vector Control) 1:200 (Open Loop Vector Control) 1:1500 (Closed Loop Vector Control for PM)
뎔	Speed Control Accuracy	±0.2% in Open Loop Vector Control (25°C±10°C) ^{*1} , ±0.02% in Closed Loop Vector Control (25°C±10°C)
Control	Speed Response	10 Hz in Open Loop Vector Control (25°C±10°C), 50 Hz in Closed Loop Vector Control (25°C±10°C) (excludes temperature fluctuation when performing Rotational Auto-Tuning)
	Torque Limit	All vector control modes allow separate settings in four quadrants
	Torque Accuracy	±5%
	Accel/Decel Time	0.00 to 6000.0 s (4 selectable combinations of independent acceleration and deceleration settings)
	Braking Torque	Approximately 125% when using a braking resistor option
	V/f Characteristics	User-selected programs and V/f preset patterns possible
	Main Control Functions	Torque compensation at start (with or without sensors), Auto-Tuning (for motor and encoder offset), braking sequence, Feed Forward, Short Floor, Advanced Short Floor, Rescue Operation using back-up power supply, Light Load Direction Search, Removable Terminal Block with Parameter Backup, Direct Landing
	Motor Protection	Thermistor
	Momentary Overcurrent Protection	Drive stops when output current exceeds 200% of rated output current
Suc	Overload Protection	Drive stops after 60 s at 150% of rated output current *2
Functions	Overvoltage Protection	200 V class: Stops when DC bus exceeds approx. 410 V 400 V class: Stops when DC bus exceeds approx. 820 V
Protection	Undervoltage Protection	200 V class: Stops when DC bus exceeds approx. 190 V 400 V class: Stops when DC bus exceeds approx. 380 V
ᇫ	Heatsink Overheat Protection	Thermistor
	Stall Prevention	Stall prevention during acceleration
	Ground Fault Protection	Protection by electronic circuit*3
	Charge LED	Charge LED remains lit until DC bus has fallen below approx. 50 V
	Area of Use	Indoors
nent	Ambient Temperature	-10 to 40°C (open-chassis), -10 to 50°C (NEMA Type 1)
Environment	Humidity	95% RH or less (no condensation)
En.	Storage Temperature	-20 to 60°C (short-term temperature during transportation)
	Altitude	Up to 1000 meters
	Shock	10 Hz to 20 Hz, 9.8 m/s² max. 20 Hz to 55 Hz, 5.9 m/s² max.
Sta	ndards Compliant	UL508C, EN61800-3, EN61800-5-1, EN954-1 Cat. 3, ISO13849-1 (Cat. 3, PLd), IEC/EN61508 SIL2
Pro	tective Design	IP00 open-chassis, NEMA Type 1 enclosure*4
		elightly depending on installation conditions or motor used. Contact Vaskawa for details

- * 1: Speed control accuracy may vary slightly depending on installation conditions or motor used. Contact Yaskawa for details.
- * 2: Overload protection may be triggered when operating for 60 s with 150% of the rated output current if the output frequency is less than 6 Hz.
- * 3: Protection may not be provided under the following conditions as the motor windings are grounded internally during run:
 - Low resistance to ground from the motor cable or terminal block.
 - •Drive already has a short-circuit when the power is turned on.
- * 4: Removing the cover from a NEMA Type 1 model drive (models CIMR-LT2A0008 to 2A0075, CIMR-LT4A0005 to 4A0039) converts the enclosure rating to IP20.

Dimensions

■ Enclosure Panel (NEMA Type 1)




Figure 1




Figure 2

	Applicable	Model	Fig					Dim	ensions (mm)					Weight
	Motor (kW)	CIMR-LT2A []	Figure	W	Н	D	W1	H1	H0	H2	H3	D1	t1	d	(kg)
	1.5	0008		140	260	147	122	248	ı	6	_	38	5	M5	3.2
	2.2	0011		140	260	147	122	248	_	6	_	38	5	M5	3.2
200 V	3.7	0018		140	260	164	122	248	_	6	_	55	5	M5	3.5
Class	5.5	0025	1	140	260	167	122	248	_	6	_	55	5	M5	4.0
	7.5	0033		140	260	167	122	248	_	6	_	55	5	M5	4.0
	11	0047		180	300	187	160	284	_	8	_	75	5	M5	5.6
	15	0060		220	350	197	192	335	_	8	_	78	5	M6	8.7
	18.5	0075	2	220	365	197	192	335	350	8	15	78	5	M6	9.7
	Applicable	Model	Figure					Dim	ensions (mm)					Weight
	Motor (kW)	CIMR-LT4A	ure	W	Н	D	W1	H1	H0	H2	H3	D1	t1	d	(kg)
	1.5	0005		140	260	147	122	248	ı	6	_	38	5	M5	3.2
	2.2	0006		140	260	164	122	248	ı	6	_	55	5	M5	3.4
400 V	3.7	0009		140	260	164	122	248	_	6	_	55	5	M5	3.5
Class	5.5	0015	1	140	260	167	122	248	_	6	_	55	5	M5	3.9
	7.5	0018		140	260	167	122	248	_	6	_	55	5	M5	3.9
	11	0024		180	300	167	160	284	_	8	_	55	5	M5	5.4
	15	0031		180	300	187	160	284	-	8	_	75	5	M5	5.7
	18.5	0039	2	220	350	197	192	335	_	8	_	78	5	M6	8.3

■ Open-Chassis (IP00)




Figure 1

	Applicable	Model	Figure					Dimension	ons (mm)					Weight
	Motor (kW)	CIMR-LT2A []	ure	W	Н	D	W1	H1	H2	D1	t1	t2	d	(kg)
	22	0085		250	400	258	195	385	7.5	100	2.3	2.3	M6	21
	30	0115		275	450	258	220	435	7.5	100	2.3	2.3	M6	25
200 V	37	0145		325	550	283	260	535	7.5	110	2.3	2.3	M6	37
Class	45	0180	_	325	550	283	260	535	7.5	110	2.3	2.3	M6	38
	55	0215] '	450	705	330	325	680	12.5	130	3.2	3.2	M10	76
	75	0283]	450	705	330	325	680	12.5	130	3.2	3.2	M10	80
	90	0346]	500	800	350	370	773	13	130	4.5	4.5	M12	98
	110	0415	1	500	800	350	370	773	13	130	4.5	4.5	M12	99
	Applicable	Model	Fig					Dimension	ons (mm)					Weight
	Applicable Motor (kW)	Model CIMR-LT4A []	Figure	W	Н	D	W1	Dimension H1	ons (mm) H2	D1	t1	t2	d	Weight (kg)
			Figure	W 250	H 400	D 258	W1 195		-	D1 100	t1 2.3	t2 2.3	d M6	
	Motor (kW)	CIMR-LT4A	Figure					H1	H2					(kg)
400 V	Motor (kW)	CIMR-LT4A [] 0045	Figure	250	400	258	195	H1 385	H2 7.5	100	2.3	2.3	M6	(kg) 21
400 V Class	Motor (kW) 22 30	0045 0060		250 275	400 450	258 258	195 220	H1 385 435	H2 7.5 7.5	100 100	2.3	2.3 2.3	M6 M6	(kg) 21 25
	Motor (kW) 22 30 37	0045 0060 0075	Figure 1	250 275 325	400 450 510	258 258 258	195 220 260	H1 385 435 495	H2 7.5 7.5 7.5	100 100 105	2.3 2.3 2.3	2.3 2.3 3.2	M6 M6 M6	(kg) 21 25 36
	Motor (kW) 22 30 37 45	0045 0060 0075 0091		250 275 325 325	400 450 510 510	258 258 258 258 258	195 220 260 260	H1 385 435 495 495	H2 7.5 7.5 7.5 7.5	100 100 105 105	2.3 2.3 2.3 2.3	2.3 2.3 3.2 3.2	M6 M6 M6 M6	(kg) 21 25 36 36
	Motor (kW) 22 30 37 45 55	0045 0060 0075 0091 0112		250 275 325 325 325	400 450 510 510 550	258 258 258 258 258 283	195 220 260 260 260	H1 385 435 495 495 535	H2 7.5 7.5 7.5 7.5 7.5	100 100 105 105 110	2.3 2.3 2.3 2.3 2.3	2.3 2.3 3.2 3.2 2.3	M6 M6 M6 M6 M6	(kg) 21 25 36 36 41

Watt Loss and Drive Derating

Watt Loss Data

	Applicable	Model		Carrier Frequency	uency 8 kHz	
	Motor (kW)	CIMR-LT2A::::::	Rated Amps (A)	Heatsink Loss (W)	Interior Unit Loss (W)	Total Loss (W)
	1.5	8000	8	43	52	95
	2.2	0011	11	64	58	122
	3.7	0018	17.5	101	67	168
	5.5	0025	25	194	92	287
	7.5	0033	33	214	105	319
	11	0047	47	280	130	410
200 V	15	0060	60	395	163	558
Class	18.5	0075	75	460	221	681
	22	0085	85	510	211	721
	30	0115	115	662	250	912
	37	0145	145 *	816 *	306 *	1122 *
	45	0180	180 *	976 *	378 *	1354 *
	55	0215	215 *	1514 *	466 *	1980 *
	75	0283	283 *	1936 *	588 *	2524 *
	90	0346	346 *	2564 *	783 *	3347 *
	110	0415	415 *	2672 *	954 *	3626 *
	Applicable	Model		Carrier Frequency		
	Motor (kW)	CIMR-LT4A::::::	Rated Amps (A)	Heatsink Loss (W)	Interior Unit Loss (W)	Total Loss (W)
	1.5	0005	4.8	37	49	87
	2.2	0006	5.5	48	53	101
	3.7	0009	9.2	69	61	130
	5.5	0015	14.8	135	86	221
	7.5	0018	18	150	97	247
400 V	11	0024	24	208	115	323
Class	15	0031	31	263	141	403
Class	18.5	0039	39	330	179	509
	22	0045	4.5	349	170 l	518
	22	0045	45			
	30	0060	60	484	217	701
-	30 37	0060 0075	60 75	484 563	217 254	701 817
-	30 37 45	0060 0075 0091	60 75 91	484 563 723	217 254 299	701 817 1022
-	30 37 45 55	0060 0075 0091 0112	60 75 91 112 *	484 563 723 908 *	217 254 299 416 *	701 817 1022 1325 *
-	30 37 45 55 75	0060 0075 0091 0112 0150	60 75 91 112 * 150 *	484 563 723 908 * 1340 *	217 254 299 416 * 580 *	701 817 1022 1325 * 1920 *
	30 37 45 55	0060 0075 0091 0112	60 75 91 112 *	484 563 723 908 *	217 254 299 416 *	701 817 1022 1325 *

^{* 1:} These values assume the carrier frequency is set to 5 kHz.

Derating

The drive can be operated at above the rated temperature, altitude, and default carrier frequency by derating the drive capacity. A drive with a rated output current of 10 A can be derated to having an output current of 8 A, thus allowing the drive to operate continuously at a higher temperature.

Derating as the carrier frequency

As the carrier frequency of the drive is increased above the default setting, the drive's rated output current must be derated according to Figure 1 to Figure 4.




Figure 1. CIMR-LT2A0018 to 2A0115

Figure 2. CIMR-LT2A0145 to 2A0415





Figure 3. CIMR-LT4A0009 to 4A0091



Figure 4. CIMR-LT4A0112 to 4A0216

Standard Connection Diagram

CIMR-LT2A0033: 200 V Class 7.5 kW



- * 1: Remove the jumper between terminals +1 and +2 when installing a DC reactor option.
- * 2: Models CIMR-LT2A0085 to 2A0415 and 4A0045 to 4A0216 come with a built-in DC reactor.
- *3: Disable protection for built-in braking transistor (L8-55 = 1) when using a regenerative converter, regenerative unit, or braking unit (and therefore not using the built-in braking transistor).
- * 4: Drives using a braking resistor unit should wire a thermal relay so that the power supply is also shut off if overheat occurs.
- Self-cooling motors do not require wiring that would be necessary with motors using a cooling fan.
- * 6: A separate 24 V power supply is required to have the control circuit still operating while the power to the main circuit is shut off.

- * 7: For control modes that do not use a motor speed feedback signal, PG option card wiring is not necessary.


 * 8: Place jumpers to set the drive for sink or source (internal or external power supply). The default setting is for sink (internal power supply).

 * 9: The maximum output current capacity for the +V and -V terminals on the control circuit is 20 mA. Never short terminals +V, -V, and AC, as this can cause erroneous operation or damage the drive
- * 10: Enable the termination resistor in the last drive in a MEMOBUS/Modbus network by setting DIP switch S2 to the ON position.
- The sink/source setting for the Safe Disable input is the same as with the sequence input. Jumper S3 has the drive set for an external power supply. When not using the Safe Disable input feature, remove the jumper shorting the input and connect an external power supply.
- * 12: Disconnect the wire jumper between HC H1 and HC H2 when utilizing the Safe Disable input.
- * 13: Monitor outputs work with devices such as analog frequency meters, ammeters, voltmeters, and wattmeters. Do not use these outputs in a feedback loop.
- * 14: Note that if the drive is set to trigger a fault output whenever the fault restart function is activated (L5-02 = 1), then a sequence to interrupt power when a fault occurs will result in shutting off the power to the drive as the drive attempts to restart itself. The default setting for L5-02 is 0 (fault output active during restart attempt).
- * 15: MA, MB, and MC must be used as fault outputs. They must be set up so that any interruption in the safety chain shuts off drive output.
- * 16: Even though no fault is present conditions where the drive can not start can occur, e.g., when the digital operator is left in the Programming Mode. Use the "Drive Ready" output (default set to terminals M5-M6) to interlock operation in such situations.

L1000 and Yaskawa PM Motors Flat-type and base-mount motors

	Weight	Floyator Spood		Motor		L1000
	(Kg)	Elevator Speed (m/min)	Model	Motor Output	Motor Speed	CIMR-LT[[]]
	(Ng)	· · · · · · · · · · · · · · · · · · ·	SSE4-[]	(kW)	(r/min)	
		45	22P1072	2.1	72	2A0025
	450	60	22P8096	2.8	96	2A0025
		90	24P2144	4.2	144	2A0033
		45	22P8072	2.8	72	2A0033
	600	60	23P7096	3.7	96	2A0033
	000	90	25P6144	5.6	144	2A0047
		105	26P5168	6.5	168	2A0047
200 V		45	23P5072	3.5	72	2A0033
Class	750	60	24P6096	4.6	96	2A0033
	700	90	26P9144	6.9	144	2A0060
		105	28P1168	8.1	168	2A0060
		45	24P2072	4.2	72	2A0047
	900	60	25P6096	5.6	96	2A0047
	300	90	28P3144	8.3	144	2A0060
		105	29P7168	9.7	168	2A0060
		45	24P6072	4.6	72	2A0047
	1000	60	26P2096	6.2	96	2A0047
	1000	90	29P2144	9.2	144	2A0075
		105	2011168	11	168	2A0075
		45	42P1072	2.1	72	4A0015
	450	60	42P8096	2.8	96	4A0015
	430	90	44P2144	4.2	144	4A0018
		105	44P8168	4.8	168	4A0018
		45	42P8072	2.8	72	4A0018
	600	60	43P7096	3.7	96	4A0018
	000	90	45P6144	5.6	144	4A0024
		105	46P5168	6.5	168	4A0024
		45	43P2072	3.2	72	4A0018
	690	60	44P3096	4.3	96	4A0018
	300	90	46P9144	6.9	144	4A0031
400 V		105	48P1168	8.1	168	4A0031
Class		45	43P2072	3.5	72	4A0018
0.000	750	60	44P3096	4.6	96	4A0018
	, 00	90	46P9144	6.9	144	4A0031
		105	48P1168	8.1	168	4A0031
		45	44P2072	4.2	72	4A0018
	900	60	45P6096	5.6	96	4A0018
	300	90	48P3144	8.3	144	4A0031
		105	49P7168	9.7	168	4A0031
		45	44P6072	4.6	72	4A0024
		60	46P2096	6.2	96	4A0024
	1000	90	49P2144	9.2	144	4A0031
		105	4011168	11	168	4A0031
		120	4013192	13	192	4A0039

Model Number Key



Peripherals Devices and Options

	Device	Model		Purpose						
Inte	erface Options	Wodo		i diposo						
Ор	erator Extension Cable	WV001/WV003		ng the LED operator (1 m or 3 m cables available) AT5e cable (T568B)						
US	B Copy Unit	JVOP-181	another drive. Cable	ettings in a single step, then transfer those settings to e included.						
Ор	erator Mounting Bracket									
Ins	tallation Support Set A	EZZ020642A	Mounts the digital o	operator to the outside of an enclosure panel. For use the panel.						
Ins	tallation Support Set B	EZZ020642B	Mounts the digital operator to the outside of an enclosure panel. For use with mounted threaded studs.							
Oth	er Options									
24	V Power Supply	PS-A10LB PS-A10HB	main circuit loses p	for the control circuit and option boards for when the lower. Allows the user to refer to parameter settings hitors during a power loss.						
Ор	tion Cards									
	Complimentary Type PG	PG-B3		For complimentary and open collector types: 3 track (A, B, Z pulse) Single track compatible (A pulse) Maximum input frequency: 50 kHz Pulse monitor output: Open collector						
ır Card	Line Driver PG	PG-X3	Pulse generators and encoders are	Voltage output for PG: 12 V, max. 200 mA For line drivers: 3 track (A, B, Z pulse) Single track compatible (A pulse) Maximum input frequency: 300 kHz Pulse monitor: Matches RS-422 Voltage output for PG: 5 or 12 V, max. 200 mA						
PG Speed Controller	Encoder Type (EnDat)	PG-F3	combined with a feedback signal to detect motor speed. Allows the drive to control the output frequency to keep motor speed constant.	For HEIDENHAIN EnDat2.1/01, EnDat2.2/01, EnDat2.2/22: Maximum input frequency: 20 kHz Pulse monitor: Matches RS-422 Voltage output for encoder: 5 V, 330 mA max or 8 V, 150 mA max. Encoder cable: 20 m max.* Pulse monitor cable: 30 m max. *Use a 17-pin encoder capable manufactured by HEIDENHAIN.						
	Encoder Type (ERN1387)	PG-E3		For HEIDENHAIN ERN1387: Maximum input frequency: 20 kHz Pulse monitor: Matches RS-422 Voltage output for encoder: 5 V, 200 mA max. Encoder cable: 10 m max.* Pulse monitor cable: 30 m max. *Use a 17-pin encoder capable manufactured by HEIDENHAIN.						
ards	Analog Monitor	AO-A3	output current, etc.) Terminals: 2 analog	nal for monitoring drive output state (output frequency,). g outputs 11 bit signed (1/2048)						
Option Cards	Digital Input	DI-A3	Terminals: 18 input	speed reference input. terminals (including those for set and sign) set binary 8/12/16 bit, BCD 2/3/4 c. 8 mA						
0/1	Digital Output	DO-A3	Outputs isolated typesignal, zero speed of Terminals: 6 photocol	pe digital signal for monitoring drive run state (alarm						
Communications	CANopen	SI-S3	Connects the drive	to a CANopen network.						

Peripherals Devices

■ Braking Unit




(CDBR series)


Voltage		200 V Class	3	400 V Class				
Model: CDBR-L	2022D	2037D	2110D	4030D	4045D	4220D		
Max. Applicable Motor (kW)	22	37	110	30	45	220		
Max. Discharge Current A/10%ED(10 s max.)	60	80	250	40	60	250		
Rated Discharge Current A/continues	20	24	80	15	18	80		
Min. Connectable Resistance (Ω)	6.4	5.0	1.6	19.2	12.8	3.2		
Drive Watts Loss (Heat loss) (W)	27	38	152	24	36	152		

Dimensions (mm)

Open-Chassis [IP20] Model: CDBR-2022D, -2037D, -4030D, 4045D




Open-Chassis [IP00] Model: CDBR-2110D, -4220D



Enclosure Panel [NEMA Type1]


Model: CDBR-2022D, -2037D, Model: CDBR-2110D, -4220D



■ Power Regenerative Unit R1000



200 V	Max. Applicable Motor Capacity kW	3.7	5.5	7.5	11	15	18.5	22	30	37	55	75	110	
Class	Model CIMR-RT2A	03P5	0005	0007	0010	0014	0017	0020	0028	0035	0053	0073	0105	
400 V	Max. Applicable Motor Capacity kW	3.7	5.5	7.5	11	15	18.5	22	30	37	45	55	75	110
Class	Model CIMR-RT4A	03P5	0005	0007	0010	0014	0017	0020	0028	0035	0043	0053	0073	0105



Refer to the catalog (No.KAEPC71065605) for details.

■ 24 V Power Supply

The 24 V Power Supply Option maintains drive control circuit power in the event of a main power outage. The control circuit keeps the network communications and I/O data operational in the event of a power outage.




Weight: 0.2kg



Model	Code No.
200 V Class: PS-A10LB	PS-A10LB
400 V Class: PS-A10HB	PS-A10HB

Connection Diagram



Note: Even if a back-up power supply is used for the control circuit, the main circuit must still have power in order to charge parameter settings.


Peripherals Devices

■ DC Reactor (UZDA-B for DC circuit)


Base device selection on motor capacity.




Lead Wire Type



Note: Reactor recommended for power supplies larger than 600 kVA.



Dimensions (mm)






Figure 2


	I Canacity I	current Inductance Code N		Figure	Dimensions (mm)										Weight	Watt	Wire*	
	Capacity (kW)	(A)	(mH)	Code No.	Figure	Х	Y2	Y1	Z	В	Н	K	G	φ1	φ2	(kg)	Loss (W)	Gauge (mm ²⁾
	1.5																	
	2.2	18	3	X010049		86	80	36	76	60	55	18	_	M4	M5	2	18	5.5
200 V	3.7																	
Class	5.5	36	1	X010050	1	105	90	46	93	64	80	26	_	M6	M6	3.2	22	8
	7.5	36 1	A010050	'	103	90	40	90	04	00	20		IVIO	IVIO	5.2	22	O	
	11	72	0.5	X010051		105	105	56	93	64	100	26	_	M6	M8	4.9	29	30
	15	12	0.5	X010031		103	103	30	90	04	100	20		IVIO	IVIO	4.5	29	30
	18.5	90	0.4	X010176		133	120	52.5	117	86	80	25	ı	M6	M8	6.5	45	30
	22~110								Built-	in								

	Motor	Current	Inductance						Di	mensic	ns (mr	n)				Weight	Watt	Wire*
	Capacity (kW)	(A)	(mH)	Code No.	Figure	Х	Y2	Y1	Z	В	Ξ	K	G	φ1	φ2	(kg)	Loss (W)	Gauge (mm ²⁾
	1.5	5.7	11	X010053	2	90			60	80		_	32	M4	_	1	11	2
	2.2															·		_
400 V	3.7	12	6.3	X010054		86	80	36	76	60	55	18	-	M4	M5	2	16	2
400 V Class	5.5	23	3.6	X010055		105	90	46	93	64	80	26		M6	M5	3.2	27	5.5
	7.5	25	3.6	X010033	,	103	30	40	33	04	00	20		I WIO	IVIO	5.2	21	0.0
	11	33	1.9	X010056	'	105	95	51	93	64	90	26		M6	M6	1	26	8
	15	33	1.9	X010050		103	95	51	93	04	90	20	_	IVIO	IVIO	4	20	0
	18.5	47	1.3	X010177		115	125	57.5	100	72	90	25	Ī	M6	M6	6	42	14
	22~110								Built-	in					, The state of the	· ·		·


^{*} Cable: Indoor PVC(75°C), ambient temperature 45°C, 3 lines max.



Terminal Type
Dimensions (mm)







	Motor	Current	Inductance		Figure	Dimensions (mm)										Weight	Watt
	Capacity (kW)	(A)	(mH)	Code No.		Х	Y2	Y1	Z	В	Н	K	G	φ1	φ2	(kg)	Loss (W)
	1.5																
	2.2	18	3	300-027-131		86	84	36	101	60	55	18	-	M4	M4	2	18
200 V	3.7																
Class	5.5	36	1	300-027-132	1	105	94	46	129	64	80	26	_	M6	M4	3.2	22
	7.5	30	ı	300-027-132	'	103	94	40	129	04	60	20		IVIO	IVI 4	3.2	
	11	72	0.5	300-027-133		105	124	56	135	64	100	26	_	M6	M6	4.9	29
	15	12	0.5	300-027-133		105	124	50	133	04	100	20		IVIO	IVIO	4.9	29
	18.5	90	0.4	300-027-139		133	147.5	52.5	160	86	80	25	_	M6	M6	6.5	44

	Motor	Current	Inductance	Code No	F:				D	imensio	ons (mn	1)				Weight	Watt
	Capacity (kW)	(A)	(mH)	Code No.	Figure	Х	Y2	Y1	Z	В	Н	K	G	φ1	φ2	(kg)	Loss (W)
	1.5	5.7	11	300-027-135	2	90			88	80			32	M4	M4	1	11
	2.2	5.7	11	300-027-135	2	90	_		00	80	_	_	32	IVI4	IVI 4	ı	11
400 V	3.7	12	6.3	300-027-136		86	84	36	101	60	55	18	_	M4	M4	2	16
Class	5.5	23	3.6	300-027-137		105	104	46	118	64	80	26	_	M6	M4	3.2	27
	7.5	23	3.0	300-027-137	1	105	104	40	110	04	00	20	1	IVIO	IVI4	3.2	21
	11	33	1.9	300-027-138	'	105	109	51	129	64	90	26		M6	M4	4	26
	15	33	1.9	300-027-136		105	109	וכ	129	04	90	20		IVIO	1014	4	20
	18.5	47	1.3	300-027-140		115	142.5	57.5	136	72	90	25	_	M6	M5	5	42

■ Fuse and Fuse Holder

Install a fuse to the drive input terminals to prevent damage in case a fault occurs. Refer to the instruction manual for information on UL-approved components.



[Fuji Electric FA Components & System Co., Ltd]

	Model	Fuse		Fuse Ho	lder
	CIMR-LT2A□	Model	Qty.	Model	Qty.
	8000	CR2LS-50			
	0011	CR2L5-50		CM-1A	1
	0018	CR2LS-100			
	0025	CR2L-125			
	0033	CR2L-150		CM-2A	1
	0047	CR2L-175			
200 V	0060	CR2L-225			
Class	0075	CR2L-260	3		
	0085	CR2L-300	3		
	0115	CR2L-350			
	0145	CR2L-400		*	
	0180	CR2L-450		•	
	0215				
	0283	CR2L-600			
	0346				
	0415	CS5F-800			

	CIMR-LT4A□	Model	Qty.	Model	Qty.
	0005				
	0006	CR6L-50		CMS-4	1
	0009				
	0015	CR6L-75			
	0018	CROL-75			
	0024	CR6L-100		CMS-5	1
400 V	0031	CR6L-150			
Class	0039	CROL-150	3		
	0045	CR6L-200	3		
	0060	CR6L-250			
	0075	CR6L-250			
	0091	CR6L-300		*	
	0112	CR6L-350		•	
	0150	CR6L-400			
	0180	CS5F-600			
	0216	C331-000			

Fuse

Model

Fuse Holder

^{*} Manufacture does not recommended a specific fuse holder for this fuse. Contact the manufacture for information on fuse dimensions.

L1000A

DRIVE CENTER (INVERTER PLANT)

2-13-1, Nishimiyaichi, Yukuhashi, Fukuoka, 824-8511, Japan Phone 81-930-25-3844 Fax 81-930-25-4369 http://www.yaskawa.co.jp

YASKAWA ELECTRIC CORPORATION

New Pier Takeshiba South Tower, 1-16-1, Kaigan, Minatoku, Tokyo, 105-6891, Japan Phone 81-3-5402-4502 Fax 81-3-5402-4580 http://www.yaskawa.co.jp

YASKAWA AMERICA, INC.

2121, Norman Drive South, Waukegan, IL 60085, U.S.A. Phone 1-800-YASKAWA (927-5292) or 1-847-887-7000 Fax 1-847-887-7310 http://www.yaskawa.com

YASKAWA ELÉTRICO DO BRASIL LTDA.

777, Avenida Piraporinha, Diadema, São Paulo, 09950-000, Brasil Phone 55-11-3585-1100 Fax 55-11-3585-1187 http://www.yaskawa.com.br

YASKAWA EUROPE GmbH

185, Hauptstraβe, Eschborn, 65760, Germany Phone 49-6196-569-300 Fax 49-6196-569-398 http://www.yaskawa.eu.com

YASKAWA ELECTRIC KOREA CORPORATION
9F, Kyobo Securities Bldg., 26-4, Yeouido-dong, Yeongdeungpo-gu, Seoul, 150-737, Korea Phone 82-2-784-7844 Fax 82-2-784-8495 http://www.yaskawa.co.kr

YASKAWA ELECTRIC (SINGAPORE) PTE. LTD.

151, Lorong Chuan, #04-02A, New Tech Park 556741, Singapore Phone 65-6282-3003 Fax 65-6289-3003 http://www.yaskawa.com.sg

YASKAWA ELECTRIC (THAILAND) CO., LTD.

252/125-126, 27th Floor, Muang Thai-Phatra Tower B, Rachadapisek Road, Huaykwang, Bangkok, 10310, Thailand Phone 66-2693-2200 Fax 66-2693-4200 http://www.yaskawa.co.th

PT. YASKAWA ELECTRIC INDONESIA

Secure Building-Gedung B Lantai Dasar & Lantai 1 Jl. Raya Protokol Halim Perdanakusuma, Jakarta 13610, Indonesia Phone 62-21-2982-6470 Fax 62-21-2982-6471 http://www.yaskawa.co.id/

YASKAWA ELECTRIC (CHINA) CO., LTD. 22F, One Corporate Avenue, No.222, Hubin Road, Shanghai, 200021, China Phone 86-21-5385-2200 Fax 86-21-5385-3299 http://www.yaskawa.com.cn

YASKAWA ELECTRIC (CHINA) CO., LTD. BEIJING OFFICE

Room 1011, Tower W3 Oriental Plaza, No.1 East Chang An Ave., Dong Cheng District, Beijing, 100738, China Phone 86-10-8518-4086 Fax 86-10-8518-4082

YASKAWA ELECTRIC TAIWAN CORPORATION

9F, 16, Nanking E. Rd., Sec. 3, Taipei, 104, Taiwan Phone 886-2-2502-5003 Fax 886-2-2505-1280 http://www.yaskawa-taiwan.com.tw

YASKAWA INDIA PRIVATE LIMITED

#17/A, Electronics City, Hosur Road, Bangalore, 560 100 (Karnataka), India Phone 91-80-4244-1900 Fax 91-80-4244-1901 http://www.yaskawaindia.in



YASKAWA ELECTRIC CORPORATION

In the event that the end user of this product is to be the military and said product is to be employed in any weapons systems or the manufacture thereof, the export will fall under the relevant regulations as stipulated in the Foreign Exchange and Foreign Trade Regulations. Therefore, be sure to follow all procedures and submit all relevant documentation according to any and all rules, regulations and laws that may apply. Specifications are subject to change without notice for ongoing product modifications and improvements

© 2009-2015 YASKAWA ELECTRIC CORPORATION.